

### Suede Additives-Medium and Coarse

# 287112SP/04, 287113SP/04

The Matthews Suede Additives 287112SP/04 (medium) and 287113SP/04 (coarse) will produce a uniform textured finish in any MAP®, SVOC, or MAP-LV topcoat or clear product.

Create a variety of textures from fine to coarse based on which suede additive is used and by altering the amount added to the ready-to-spray topcoat or clear.

287112SP/04 / 287113SP/04 is 100% solids and contains no added VOC.



## **Compatible Surfaces:**

#### Textured Matthews topcoats or clears may be applied over properly prepared:

6001SP/01 Polyester Primer Surfacer 74350SP/01 3.5 Non-Chromate Primer LVU100/01 Ultra Low VOC Epoxy Primer

6007SP/01 3.5 Gray Epoxy Primer 74734SP/01 Metal Pretreatment

 274685SP/01 U Prime
 74760SP/01 PT Filler

 274808SP/01 Black Epoxy Primer
 74770SP/01 HBPT

 274908SP/01 White Epoxy Primer
 74780SP/01 HBEF

 274528SP/01 2.1 VOC Gray Epoxy Primer
 74777SP/01 Tie Bond

274530SP/01 2.1 VOC White Epoxy Primer 274777SP/01 Low VOC Tie Bond 274531SP/01 2.1 VOC Black Epoxy Primer 274793SP/01 Low VOC Spray Bond

#### **Associated Products:**

Any Matthews Conventional, Low VOC, or Ultra Low VOC colors (including associated catalysts and reducers) Any Matthews Conventional, Low VOC, or Ultra Low VOC clears (including associated catalysts and reducers)

Product Information Effective 12/22 MPC184

# 287112SP/04, 287113SP/04

### **Directions for Use**

#### **Surface Preparation:**



Substrate should be prepared according to Matthews Substrate Preparation Guide prior to topcoat application.

#### Mix Ratio:

- Catalyze and reduce Matthews topcoat or clear as per specific Technical Data Sheet (TDS).
- Add 5% to 15% by weight of desired suede additive.
- Mix well before using.
- Do not strain before use.
- If applicable, remove cup filters before using this product.

\*Variations in texture can be caused by application, equipment, temperature, solvent selection, accelerator choice, etc.

For information regarding Additives, Application, and Dry Times, refer to specific Technical Data Sheets (TDS) for the topcoat or clear being used.

#### Spray Set Up:



Air Pressure: Conventional: 40 - 50 psi at the gun\*
HVLP: 10 psi at the cap\*

\* Refer to spray gun manufacturer recommendations for inlet pressure.



Pressure Pot Fluid Delivery: 8 - 12 Fluid Ounces per Minute



Gun Set Up:

Siphon Feed: 1.4 - 1.6 mm 0.055 - 0.0629 fluid tip HVLP: 1.4 - 1.6 mm 0.055 - 0.0629 fluid tip Pressure Pot: 1.0 - 1.2 mm 0.039 - 0.047 fluid tip

# 287112SP/04, 287113SP/04

### Technical Data: VOC Information

VOC Packaged 0 lbs/gal VOC Packaged 0 g/L

VOC Actual RTS Refer to TDS of topcoat or clear being used VOC Regulatory (less water less exempt) RTS Refer to TDS of topcoat or clear being used

For complete VOC information, visit MatthewsPaint.com > Quick Links > VOC Data

#### **Performance Characteristics**

Volume solids (RTS)

Refer to TDS of topcoat or clear being used
Theoretical Coverage (1 mil @ 100% transfer efficiency)

Refer to TDS of topcoat or clear being used

Theoretical Coverage (1 mil @ 100% transfer efficiency)
Application Conditions - Temperature

60°F (16°C) Minimum 100°F (38°C) Maximum

Application Conditions - Relative Humidity

85% maximum 5° above dew point

#### Important:

The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels of all components, since the mixture will have the hazards of all its parts. Improper spray technique may result in a hazardous condition. Follow spray equipment manufacturer's instructions to prevent personal injury or fire. Follow directions for respirator use. Wear eye and skin protection. Observe all applicable precautions.

See Safety Data Sheet and Labels for additional safety information and handling instructions.

EMERGENCY MEDICAL OR SPILL CONTROL INFORMATION - US (412) 434-4515; CANADA (514) 645-1320; Mexico 01-800-00-21-400 Materials described are designed for application by professional, trained personnel using proper equipment and are not intended for sale to the general public. Products mentioned may be hazardous and should only be used according to directions, while observing precautions and warning statements listed on label. Statements and methods described are based upon the best information and practices known to Matthews Paint. Procedures for applications mentioned are suggestions only and are not to be construed as representations or warranties as to performance, results, or fitness for any intended use, nor does Matthews Paint warrant freedom from patent infringement in the use of any formula or process set forth herein. If you require technical assistance, please call us toll-free 800/323-6593.

# 287112SP/04, 287113SP/04

# **Suede Additives-Medium and Coarse**



The World's Finest Coating For Architectural Signage

760 Pittsburgh Drive
Delaware, OH 43015
Toll Free: 800/323-6593
Toll Free FAX: 800/947-0377